

Using the information below you will be able to use the GEOiD software on a PC (PCL license);

Download and register:

a) Download the GEOiD software: <http://www.geo-instrument.com/GEOiD.asp>.

b) After installation (with Administrator rights) of the GEOiD software as PCL (local license), start the software by clicking the icon on your desktop.

c) On startup a message indicates that the COL-server was not Found. Select Viewer-Demo. The window Help - About will appear.

d) Go to <http://www.geo-instrument.com/Weblicense.asp> and enter the data asked for.

Username:

Password :

And login

e) ID1 and ID2 can be found in the window Help - About which already is open and copy ID1 to the field ID1 in the Webpage. Do the same for ID2;

f) Enter the computername.;

g) Close GEOiD and save QuinqS.dll in C:\Programdata\GEOiD\System\; Restart GEOiD.

If you have any questions, please contact our helpdesk.